

BLACK OUTSIDE. YELLOW INSIDE.



Zipper Area For Tripod Pull Out Pocket

> Pull Out Pocket For Tripod (Tucks Away When Not In Use)





BLACK OUTSIDE. YELLOW INSIDE.

4 D-Rings Attached To Harness For:

- Key Chains
- Water Bottle Holders
- Lanyards
- Carabiner Clips
- Straps For Attaching Your Camera
- And So Much More



Extra Black Strap With Reinforced Stitched Areas On Each Shoulder Strap Creating 5 Separate Areas To Attach Small Accessory Bags And Other Miscellaneous Pieces You Want Quick Access To



Hidden Compartment For Retractable All-Weather Water-Resistant Cover



Reinforced Stitched Strap To Attach External Lens Cases Or Other Accessory Bags

2 Side Zippered Pockets For Small Accessories (1 On Each Side)



2 Side Zippered External Mesh Pockets For Small/ Lightweight Accessories (1 On Each Side)



Once The Water-Resistant Cover Is Pulled Out; Pull It From The Bottom Back, Under And Around To Cover The Top






# **ACPRO2DR Outer Zippered Pocket**

Clasp To Attached Your Key Chain

Pockets For Files, Papers, Magazines, Etc.



- Mesh Pockets For Pencils, Pens, Cords, Etc.



## **ACPRO2DR Laptop Compartment**



Fully customizable interior for drone and controller.

Pocket For props, POV camera, batteries and other accessories.







BLACK OUTSIDE. YELLOW INSIDE.