



Double zippers that access the main compartment.

2 Stitched strap to attach external lens cases and other small cases you may want to bring along (one on each side).







Back sleeve for your phone or small tablet has a Velcro closure when not in use.





BLACK OUTSIDE. YELLOW INSIDE.
TOUGH ALL OVER!



BLACK OUTSIDE. YELLOW INSIDE.
TOUGH ALL OVER!



BLACK OUTSIDE. YELLOW INSIDE.
TOUGH ALL OVER!





Three nylon and one zippered pocket for media cards and other small items on the lid of the case.

Adjustable padded inserts to help contour to your equipment and keep it protected.



Hi-Vis™ Yellow interior to help find things in low light.