Strap With Reinforced Stitched Areas Creating 4 Separate Areas To Attach Small Accessory Bags And Other Miscellaneous Pieces You Want Quick Access To

2 Front External Mesh Pockets For Small/Lightweight Accessories

2 Front Easy Access Tripod Straps









Zipper Area For Tripod Pull Out Pocket

> Pull Out Pocket For Tripod (Tucks Away When Not In Use)







4 D-Rings Attached

- To Harness For:
  Key Chains
- Water Bottle Holders
- Lanyards
- Carabiner Clips
- Straps For Attaching Your Camera
- And So Much More



Extra Black Strap With Reinforced Stitched Areas On Each Shoulder Strap Creating 5 Separate Areas To Attach Small Accessory Bags And Other Miscellaneous Pieces You Want Quick Access To



Hidden Compartment For Retractable All-Weather Water-Resistant Cover



Reinforced Stitched Strap To Attach External Lens Cases Or Other Accessory Bags

2 Side Zippered Pockets For Small Accessories (1 On Each Side)



2 Side Zippered External Mesh Pockets For Small/ Lightweight Accessories (1 On Each Side)



BLACK OUTSIDE. YELLOW INSIDE.

Once The Water-Resistant Cover Is Pulled Out; Pull It From The Bottom Back, Under And Around To Cover The Top





### **ACPRO4000 Trolley Features**



Integrated easy-access telescopic handle with 4 length variations

Adjustable trolley base helps with balance when backpack is full



in-line style wheels



BLACK OUTSIDE. YELLOW INSIDE.

# ACPRO4000 Outer Zippered Pocket

Clasp To Attached Your Key Chain

Pockets For Files, Papers, Magazines, Etc.



Mesh Pockets For Pencils, Pens, Cords, Etc.



BLACK OUTSIDE. YELLOW INSIDE.

## **ACPRO4000 Laptop Compartment**



Completely Adjustable Padded Inserts To Suit Your Specific Wants And Needs

> Pocket For Lens Filters, Papers And Other Miscellaneous Accessories





